

6. How to make sure the device is using DHCP to get IP address, or using a fixed IP address?

1. You can visit the configuration -> network page, where if the check item in the first line "reset the IP address at next boot" is checked, it means the device will try to get new IP address via DHCP. Otherwise it means it uses the fixed IP address.